


OK. Now you need a... TOUCHSCREEN



By Dusan Mihajlovic

Mikroelektronika Hardware Department

Do you want your new device to have a simple and intuitive interface? If the answer is YES, then a graphic LCD display with touch panel is the best choice because together they create a Touchscreen (Glcd + Touch Panel = Touchscreen). In that way, with a small number of electronic components you will be able to create an attractive and easy to use device.



What is a touch panel? A touch panel is a thin, self-adhesive transparent panel placed over the screen of a graphic LCD. It is very sensitive to pressure so that even a soft touch causes some changes on output signal. There are a few types of touch panel. The simplest one is the resistive touch panel which will be discussed here.

Principle of operation

A resistive touch panel consists of two transparent rigid foils, forming a "sandwich" structure, that have resistive layers on their inner sides. The resistance of these layers usually does not exceed 1Kohm. The opposite sides of the foils have contacts available for use through a flat cable. The process of determining coordinates of the point in which the touch panel is pressed can be broken up into two steps. The first one is the determination of the X coordinate and the second one is the determination of the Y coordinate of the point. In order to determine the X coordinate, it is necessary to connect the left contact on the X surface to ground and the right contact to the power supply. This enables a voltage divider to be obtained by pressing the touch panel. The val-

ue of the divider is read on the bottom contact of the Y surface. Voltage can be in the range of 0V to the power supply and depends on the X coordinate. If the point is closer to the left contact of the X surface, the voltage will be closer to 0V. In order to determine the Y coordinate, it is necessary to connect the bottom contact on the Y surface to ground, and the upper contact to power supply.

Flat cable detail



Determination of Y coordinate






Figure 1. Touch panel internal structure



Schematic 1. Connecting Touchscreen

and Y coordinates (Refer to Schematic 1). The bottom contact of the Y surface and left contact of the X surface are connected to the microcontroller's A/D converter. The X and Y coordinates are determined by measuring voltage on these contacts, respectively. The software consists of writing a menu on graphic LCD, turning the circuit for touch panel control on/off (driving touch panel) and reading the values of A/D converter which actually represent the X and Y coordinates of the point.

Once the coordinates are determined, it is possible to decide what we want the microcontroller to do. For the purpose of illustration, let us examine Example 1. It explains how to turn on/off two digital microcontroller pins, connected to LED diodes A and B, using a display and a touch panel.




Flat cable on-board connector before...



...and after connecting touch panel.

Considering that the touch panel surface is slightly larger than the surface of the graphic LCD, in case you want greater accuracy when determining the coordinates, it is necessary to perform the software calibration of the touch panel.



mikroPASCAL for PIC® library editor with ready to use libraries such as: Ethernet, CAN, SD/MMC etc.

Functions used in the program

- ADC_Read() Read analog value
- Delay_ms() Delay
- Glcd_box() Draw filled box*
- Glcd_circle() Draw circle
- Glcd_Dot() Draw dot
- Glcd_Fill() Delete/fill display*
- Glcd_Init() LCD display initialization*
- Glcd_Line() Draw line
- Glcd_Read_Data() Read data from LCD
- Glcd_Rectangle() Draw rectangle*
- Glcd_Set_Font() Select font*
- Glcd_Set_Page() Select page
- Glcd_Set_Side() Select side of display
- Glcd_Set_X() Determine X coordinate
- Glcd_V_Line() Draw vertical line
- Glcd_Write_Char() Write character
- Glcd_Write_Data() Write data
- Glcd_Write_Text() Write text*

* Glcd library functions used in the program

Example 1: Program to demonstrate touchscreen operation

```

program TouchPanel;
var x_coord, y_coord, x_coord128, y_coord64: longint; // scaled x-y position

function GetX(): word;
begin
//reading X
PORTC.0 := 1; // DRIVEA = 1 (LEFT drive on, RIGHT drive on, TOP drive off)
PORTC.1 := 0; // DRIBEB = 0 (BOTTOM drive off)
Delay_ms(5);
result := ADC_Read(0); // reading X value from RA0 (BOTTOM)
end;

function GetY(): word;
begin
//reading Y
PORTC.0 := 0; // DRIVEA = 0 (LEFT drive off, RIGHT drive off, TOP drive on)
PORTC.1 := 1; // DRIBEB = 1 (BOTTOM drive on)
Delay_ms(5);
result := ADC_Read(1); // reading Y value from RA1 (from LEFT)
end;

begin
PORTA := 0x00; // RA0 i RA1 are analog inputs
TRISA := 0x03;
ANSEL := 0x03; // Configure other AN pins as digital I/O
ANSELH := 0;

PORTC := 0; // PORTC is output
TRISC := 0;

Glcd_Init(PORTB, 0, 1, 2, 3, 5, 4, PORTD); // Glcd_Init_EP5
Glcd_Set_Font(@font5x7, 5, 7, 32); // Choose font, see __Lib_GLCDFonts.c in Uses folder
Glcd_Fill(0); // Clear GLCD

Glcd_Write_Text('TOUCHPANEL EXAMPLE';10,0,1);
Glcd_Write_Text('MIKROELEKTRONIKA';17,7,1);
//Display Buttons on GLCD:
Glcd_Rectangle(8,16,60,48,1);
Glcd_Rectangle(68,16,120,48,1);
Glcd_Box(10,18,58,46,1);
Glcd_Box(70,18,118,46,1);
Glcd_Write_Text('BUTTON1';14,3,0);
Glcd_Write_Text('RC6 OFF';14,4,0);
Glcd_Write_Text('BUTTON2';74,3,0);
Glcd_Write_Text('RC7 OFF';74,4,0);

while (TRUE) do
begin
// read X-Y and convert it to 128x64 space
x_coord := GetX();
y_coord := GetY();
x_coord128 := (x_coord * 128) / 1024;
y_coord64 := 64 - (y_coord * 64) / 1024;

//if BUTTON1 is selected
if ((x_coord128 >= 10) and (x_coord128 <= 58) and (y_coord64 >= 18) and (y_coord64 <= 46)) then
begin
if(PORTC.6 = 0) then
begin
PORTC.6 := 1;
Glcd_Write_Text('RC6 ON';14,4,0);
end
else
begin
PORTC.6 := 0;
Glcd_Write_Text('RC6 OFF';14,4,0);
end;
end;

//if BUTTON2 is selected
if ((x_coord128 >= 70) and (x_coord128 <= 118) and (y_coord64 >= 18) and (y_coord64 <= 46)) then
begin
if(PORTC.7 = 0) then
begin
PORTC.7 := 1;
Glcd_Write_Text('RC7 ON';74,4,0);
end
else
begin
PORTC.7 := 0;
Glcd_Write_Text('RC7 OFF';74,4,0);
end;
end;
end;
Delay_ms(100);
end; //while true
end.
    
```



NOTE: Code for this example written for PIC® microcontrollers in C, Basic and Pascal as well as the programs written for AVR® and dsPIC® microcontrollers can be found on our web site www.mikroe.com/en/article/